


# Two stage proportional directional valves

digital, pilot operated, open loop, with positive spool overlap



### DPZO-A, DPZO-AEB, DPZO-AES

Pilot operated digital proportional valves without position transducer and with positive spool overlap, for open loop directional controls and not compensated flow regulations.

#### Executions:


- A without integral driver, to be coupled with separated drivers, see section 2
- AEB with basic integral digital electronic driver, analog reference signals and USB port for software functional parameters setting
- AES with full integral digital electronic driver and fieldbus interface for functional parameters setting, reference signals and real-time diagnostics

The integral digital electronic driver performs the valve's hydraulic regulation according to the reference signal and assures valve-to-valve interchangeability thanks to the factory presetting.

Size: 10 to 32

Max flow: **180** to **1500 l/min** Max pressure: **350 bar** 

# 1 MODEL CODE for STANDARD SPOOLS



5 /	* /	*	* /	*
				Seals material, see sect. ⑤, ⑥: - = NBR PE = FKM BT = HNBR
			Series	number
		see sectio - = stan 6 = optio	n 8: dard coil onal coil t	A - see sect. 9:  for 24V <sub>DC</sub> Atos drivers for 12V <sub>DC</sub> Atos drivers for low current drivers

### Hydraulic options, see sect. 8:

**B** = solenoid and integral electronics at side of port B of the main stage (side A of pilot valve) (3)

**D** = internal drain

**E** = external pilot pressure

**G** = pressure reducing valve for piloting

**Electronic options,** only for AEB and AES - see sect.  $\boxed{\textbf{10}}$ 

C=current feedback 4÷20 mA for remote transducer, only in combination with option W

= current reference input 4÷20 mA

(omit for standard voltage reference input  $\pm 10 \text{ V}$ )

**Q** = enable signal

**Z** = double power supply, enable, fault and monitor signals -12 pin connector

**W** = power limitation function - 12 pin connector

Spool siz	e	<b>3</b> (L,S,D)	<b>5</b> (L,S,D)
DPZO-1	=	-	100
DPZO-2	=	160	250
DPZO-4	=	-	480
DPZO-6	=	-	640
Naminal f	lovy (	Ilmin) at An 10har D T	

(1) Omit for A execution; AEB available only in version NP; AES available only in version BC, BP, EH

**D** = differential-progressive

P-A = Q, B-T = Q/2P-B = Q/2, A-T = Q

(2) Hydraulic symbols are represented with integral digital driver

S = progressive

L = linear

(3) In standard configuration the solenoid (config. 51 and 53) and the integral electronics (AEB, AES) are at side A of the main stage (side B of pilot valve)

# 2 ELECTRONIC DRIVERS

Valve model							A				AEB	AES
Drivers model	E-MI-A	C-01F	E-BM-A	AC-01F	E-ME-AC-01F	E-MI-	AS-IR	E-BM-	AS-PS	E-BM-AES	E-RI-AEB	E-RI-AES
Туре			Analog				Digital					
Voltage supply (V <sub>DC</sub> )	12	24	12	24	24	12	24	12	24	24	2	4
Valve coil option	/6	std	/6	std	std	/6	std	/6	std	std	st	d
Format	plu to sol	g-in enoid	DIN 4 UNDI	13700 ECAL	EUROCARD	plug to sol	_		DIN-rai	l panel	Integral	to valve
Data sheet	GC	10	GC	)25	G035	GC	20	GC	30	GS050	GS	115

Note: for main and communication connector see sections 12, 13

# 3 GENERAL NOTES

DPZO-A\* proportional valves are CE marked according to the applicable Directives (e.g. Immunity/Emission EMC Directive and Low Voltage Directive). Installation, wirings and start-up procedures must be performed according to the general prescriptions shown in table F003 and in the installation notes supplied with relevant components.

# 4 FIELDBUS - only for AES

Fieldbus allows the direct communication of the proportional valve with machine control unit for digital reference signal, diagnostics and settings of functional parameters. Analog reference signal remain available on the main connector for quick commissioning and maintenance. For detailed information about fieldbus features and specification see tech table **GS510**.

### 5 MAIN CHARACTERISTICS - based on mineral oil ISO VG 46 at 50 °C

Assembly position	Any position						
Subplate surface finishing	Roughness index, Ra 0	,4 flatness ratio 0,0	1/100 (ISO 1101)				
MTTFd valves according to EN ISO 13849	75 years, see technical	75 years, see technical table P007					
Ambient temperature range	A: standard	= -20°C ÷ +70°C,	/BT option = -4	10°C ÷ +60°C			
	AEB, AES: standard	= -20°C ÷ +60°C,	/BT option = -4	10°C ÷ +60°C			
Storage temperature range	A: standard	= -20°C ÷ +80°C,	<b>/BT</b> option = $-4$	10°C ÷ +70°C			
	AEB, AES: standard	= -20°C ÷ +70°C,	/BT option = -4	10°C ÷ +70°C			
Coil code	standard		option /6	option /18			
Coil resistance R at 20°C	3 ÷ 3,3 Ω		$2 \div 2,2 \Omega$	13 ÷ 13,4 Ω			
Max. solenoid current	2,2 A		2,75 A	1 A			
Max. power		<b>A</b> = 30W	<b>AEB, AES</b> = 50V	1			
Insulation class	H (180°) Due to the oc ISO 13732-1 and EN98			id coils, the European standards			
Protection degree to DIN EN60529	IP66/67 with mating co	nnectors					
Tropicalization	Tropical coating on ele	ectronics PCB					
Duty factor	Continuous rating (ED:	=100%)					
EMC, climate and mechanical load	See technical table G004						
Communication interface	USB Atos ASCII coding	CANopen EN50325-4 + DS4	PROFIBUS DP EN50170-2/IEC	EtherCAT 61158 IEC 61158			
Communication physical layer	not insulated USB 2.0 + USB OTG	optical insulated CAN ISO11898	optical insulated RS485	Fast Ethernet, insulated 100 Base TX			

Valve model		DPZO-*-1	DPZ	0-*-2	DPZO-*-4	DPZO-*-6	
Pressure limits	[bar]	ports <b>P, A, B, X</b> = 350; <b>T</b> = 250 (10 for option /D); <b>Y</b> = 10;					
Spool type		L5, S5, D5	L3, S3, D3		L5, S5, D5		
Nominal flow	[l/min]						
(1)	$\Delta p = 10 \text{ bar}$	100	160	250	480	640	
Δp P-T	$\Delta p = 30 \text{ bar}$	160	270	430	830	1100	
Max permissible flow	[l/min]	180	400	550	900	1500	
Piloting pressure	[bar]	min. =	25; max = 350 (o	ption /G advisable fo	or pilot pressure > 1	50 bar)	
Piloting volume	[cm <sup>3</sup> ]	1,4	3	,7	9,0	21,6	
Piloting flow (2)	[l/min]	1,7	3	,7	6,8	14,4	
Leakage (3)	Main stage [I/min]	0,15/0,5	0,2	/0,6	0,3/1,0	1,0/3,0	
Response time (4) (0-100% step signal and pil	[ms] ot pressure 100 bar)	< 80	< 100		< 120	< 180	
Hysteresis		≤ 5 [% of max regulation]					
Repeatability		± 1 [% of max regulation]					

**Notes:** above performance data refer to valves coupled with Atos electronic drivers, see section 2.

(1) for different  $\Delta p$ , see section 7.2

(2) with step reference input signal 0  $\div 100~\%$ 

(3) at p = 100/350 bar


(4) see detailed diagrams in section 7.3


# 6 SEALS AND HYDRAULIC FLUID - for other fluids not included in below table, consult our technical office


Seals, recommended fluid temperature	NBR seals (standard) = $-20^{\circ}\text{C} \div +60^{\circ}\text{C}$ , with HFC hydraulic fluids = $-20^{\circ}\text{C} \div +50^{\circ}\text{C}$ FKM seals (/PE option) = $-20^{\circ}\text{C} \div +80^{\circ}\text{C}$ HNBR seals (/BT option) = $-40^{\circ}\text{C} \div +60^{\circ}\text{C}$ , with HFC hydraulic fluids = $-40^{\circ}\text{C} \div +50^{\circ}\text{C}$					
Recommended viscosity	20 ÷ 100 mm²/s - max allowed range 15 ÷ 380 mm²/s					
Fluid contamination class	ISO 4406 class 20/18/15 NAS 1	S 1638 class 9, in line filters of 10 μm (β10 ≥75 recommended)				
Hydraulic fluid	Suitable seals type	Classification	Ref. Standard			
Mineral oils	NBR, FKM, HNBR	HL, HLP, HLPD, HVLP, HVLPD	DIN 51524			
Flame resistant without water	FKM	HFDU, HFDR	ISO 12922			
Flame resistant with water	NBR, HNBR	HFC	130 12922			


# 7 DIAGRAMS (based on mineral oil ISO VG 46 at 50 °C)


# 7.1 Regulation diagrams (values measure at $\Delta p$ 10 bar P-T)











Note: Hydraulic configuration vs. reference signal for configuration 71 and 73 (standard and option /B)

Reference signal  $\begin{array}{c} 0 \div +10 \text{ V} \\ 12 \div 20 \text{ mA} \end{array} \right\} \text{ P} \rightarrow \text{A} / \text{B} \rightarrow \text{T}$ 

Reference signal  $\begin{array}{cc} 0 \div -10 \text{ V} \\ 12 \div 4 \text{ mA} \end{array} \right\} P \rightarrow B / A \rightarrow T$ 

### 7.2 Flow /∆p diagram

stated at 100% of spool stroke

### DPZO-1:

1 = spools L5, S5, D5

#### DPZO-2:

2 = spools L3, S3, D3


**3** = spools L5, S5, D5


#### **DPZO-4**:


4 = spools L5, S5, D5


#### DPZO-6:

**5** = spools L5, S5, D5













### **7.3 Response time** (measured at pilot pressure = 100 bar)

The response times in below diagrams are measured at different steps of the reference input signal. They have to be considered as average values. For the valves with digital electronics the dynamics performances can be optimized by setting the internal software parameters.










# 7.4 Operation as throttle valve

Single solenoid valves (\*51) can be used as simple throttle valves:

Pmax = 250 bar

For this application, the use of valve -TEB or -TES (see tab. FS172) is advisable (consult our technical office)



DPZO-*-	151-L5	251-L5	451-L5	651-L5
Max flow [I/min] $\Delta p = 30 \text{ bar}$	320	850	1400	2000

### 8 HYDRAULIC OPTIONS

#### 8.1 Option /B

DPZO- $^*$ - $^*$ 5 = solenoid and integral electronics at side of port B of the main stage.

DPZO-\*-\*7 = integral electronics at side of port B of the main stage.

#### 8.2 Options /E and /D

Pilot and drain configuration can be modified as shown in section [15]

The valve's standard configuration provides internal pilot and external drain.

For different pilot / drain configuration select:

Option /E External pilot (through port X).

Option /D Internal drain.

### 8.3 Option /G

Pressure reducing valve installed between pilot valve and main body with fixed setting:

DPZO-1 and -2 = 40 bar

DPZO-4 and -6 = 100 bar

It is advisable for valves with internal pilot in case of system pressure higher than 150 bar.


### 9 OPTIONS for -A

#### 9.1 Coil voltage

Option /6 optional coil to be used with Atos drivers with power supply 12 Vbc
Option /18 optional coil to be used with electronic drivers not supplied by Atos

#### **FUNCTIONAL SCHEME**

example of configuration 7' 3 positions, spring centered



- Pilot valve
- (2) Main stage
- 3 Pressure reducing valve
- 4) Plug to be added for external pilot trough port X
- (5) Plug to be removed for internal drain through port T

# 10 ELECTRONIC OPTIONS for AEB and AES

Standard driver execution provides on the 7 pin main connector:

Power supply

- 24 Vpc must be appropriately stabilized or rectified and filtered; **2,5 A** fuse time lag is required in series to each driver power supply Apply at least a 10000  $\mu$ F/40 V capacitance to single phase rectifiers or a 4700  $\mu$ F/40 V capacitance to three phase rectifiers

Reference input signal - analog differential input with ±10 VDc nominal range (pin D, E), proportional to desired coil current

Monitor output signal - analog output signal proportional to the actual valve's coil current (1V monitor = 1A coil current)

**Note:** a minimum booting time of 500 ms has be considered from the driver energizing with the 24 Vpc power supply before the valve has been ready to operate. During this time the current to the valve coils is switched to zero.

#### 10.1 Option /I

It provides  $4 \div 20$  mA current reference signal, instead of the standard  $\pm 10$  V.

Input signal can be reconfigured via software selecting between voltage and current, within a maximum range of ±10 V or ±20 mA.

It is normally used in case of long distance between the machine control unit and the valve or where the reference signal can be affected by electrical noise; the valve functioning is disabled in case of reference signal cable breakage.

# 10.2 Option /Q

To enable the driver, supply 24 Voc on pin C referred to pin B: Enable input signal allows to enable/disable the current supply to the solenoid, without removing the electrical power supply to the driver; it is used to maintain active the communication and the other driver functions when the valve has to be disabled. This condition does not comply with European Norms EN13849-1 (ex EN954-1).

### 10.3 Option /Z

It provides, on the 12 pin main connector, the following additional features:

### **Enable Input Signal**

To enable the driver, supply 24 Vpc on pin 3 referred to pin 2: Enable input signal allows to enable/disable the current supply to the solenoid, without removing the electrical power supply to the driver; it is used to maintain active the communication and the other driver functions when the valve has to be disabled. This condition does not comply with European Norms EN13849-1 (ex EN954-1).

### **Fault Output Signal**

Fault output signal indicates fault conditions of the driver (solenoid short circuits/not connected, reference signal cable broken for 4÷20mA input, etc.). Fault presence corresponds to 0 Vpc, normal working corresponds to 24 Vpc (pin 11 referred to pin 2): Fault status is not affected by the Enable input signal

### Power supply for driver's logics and communication

Separate power supply (pin 9,10) allow to cut solenoid power supply (pin 1, 2) while maintaining active diagnostics, USB and fieldbus communication. A safety fuse is required in series to each driver power supply: 500 mA fast fuse.

10.4 Option /W - only for valves coupled with pressure compensator type KC-011 or JPC-2m (see tab. D150).

It provides, on the 12 pin main connector, the above option /Z features plus the hydraulic power limitation function.

The driver receives the flow reference signal by the analog input INPUT+ and a pressure transducer, installed in the hydraulic system, has to be connected to the driver's analog input TR.

When the actual requested hydraulic power  $p \times Q$  (TR x INPUT+) reaches the max power limit (p1xQ1), internally set by software, the driver automatically reduces the flow regulation of the valve. The higher is the pressure feedback the lower is the valve's regulated flow:

# For detailed information on hydraulic power limitation, see tab. GS115

### 10.5 Option /C - only in combination with option /W

Option /C is available to connect pressure transducer with  $4 \div 20$  mA current output signal, instead of the standard  $0 \div 10V$ . Input signal can be reconfigured via software selecting between voltage and current, within a maximum range of  $\pm 10$  V or  $\pm 20$  mA.

### 10.6 Possible combined options: /IQ, /IZ, /IW, /CW and /CWI

# 11 ELECTRONIC CONNECTIONS

# 11.1 Main connector signals - 7 pin - standard and /Q options - DPZO-AEB and DPZO-AES $\stackrel{ ext{A1}}{ ext{A1}}$

PIN	Standard	/Q	TECHNICAL SPECIFICATIONS	NOTES
Α	V+		Power supply 24 Vbc Rectified and filtered: VRMs = 20 ÷ 32 VMAX (ripple max 10 % VPP)	Input - power supply
В	V0		Power supply 0 Vpc	Gnd - power supply
С	AGND		Analog ground	Gnd - analog signal
		ENABLE	Enable (24 Vpc) or disable (0 Vpc) the driver, referred to V0	Input - on/off signal
D	INPUT+		Reference input signal: ±10 Vpc / ±20 mA maximum range Defaults are ±10 Vpc for standard and 4 ÷ 20 mA for /l option	Input - analog signal Software selectable
Е	E INPUT-		Negative reference input signal for INPUT+	Input - analog signal
F	F MONITOR referred to: AGND   V0		Monitor output signal: ±5 Vpc maximum range Default is ± 5 Vpc (1V = 1A)	Output - analog signal <b>Software selectable</b>
G	G <b>EARTH</b>		Internally connected to driver housing	

### 11.2 Main connector signals - 12 pin - /Z and /W options - DPZO-AEB and DPZO-AES (A2)

PIN	/Z	/W	TECHNICAL SPECIFICATIONS	NOTES
1	V+		Power supply 24 VDC Rectified and filtered: VRMs = 20 ÷ 32 VMAX (ripple max 10 % VPP)	Input - power supply
2	V0		Power supply 0 Vpc	Gnd - power supply
3	ENABLE		Enable (24 VDC) or disable (0 VDC) the driver, referred to V0	Input - on/off signal
4	4 INPUT+		Reference input signal: ±10 Vpc / ±20 mA maximum range Defaults are ±10 Vpc for standard and 4 ÷ 20 mA for /l option	Input - analog signal Software selectable
5	INPUT-		Negative reference input signal for INPUT+	Input - analog signal
6	MONITOR		Monitor output signal: $\pm 5$ Vpc maximum range, referred to VL0 Default is $\pm 5$ Vpc (1V = 1A)	Output - analog signal
7	NC		Do not connect	
8	NC		Do not connect	
		MONITOR2	2nd monitor output signal: ±5 VDC maximum range, default is 0 ÷ 5 VDC	Output - analog signal
9	VL+		Power supply 24 VDc for driver's logic and communication	Input - power supply
10	VL0		Power supply 0 Vpc for driver's logic and communication	Gnd - power supply
11	FAULT		Fault (0 Vbc) or normal working (24 Vbc), referred to V0	Output - on/off signal
PE	EARTH		Internally connected to driver housing	

# 11.3 Communication connectors - DPZO-AEB (B) and DPZO-AES (B) - (C)

В	USB connector - M12 - 5 pin always present				
PIN	SIGNAL	TECHNICAL SPECIFICATION (1)			
1	+5V_USB	Power supply			
2	ID	Identification			
3	GND_USB	Signal zero data line			
4	D-	Data line -			
5	D+	Data line +			

C2	BP fieldbus execution, connector - M12 - 5 pin (2)					
PIN	SIGNAL	TECHNICAL SPECIFICATION (1)				
1	+5V	Termination supply signal				
2	LINE-A	Bus line (high)				
3	DGND	Data line and termination signal zero				
4	LINE-B	Bus line (low)				
5	SHIELD					

(C1)	BC fieldbus execution, connector - M12 - 5 pin (2)					
PIN	SIGNAL	TECHNICAL SPECIFICATION (1)				
1	CAN_SHLD	Shield				
2	NC	do not connect				
3	CAN_GND	Signal zero data line				
4	CAN_H	Bus line (high)				
5	CAN_L	Bus line (low)				

©3 (	©3 ©4 EH fieldbus execution, connector - M12 - 4 pin (2)				
PIN	SIGNAL	TECHNICAL SPECIFICATION (1)			
1	TX+	Transmitter			
2	RX+	Receiver			
3	TX-	Transmitter			
4	RX-	Receiver			
Housing	SHIELD				


Notes: (1) shield connection on connector's housing is recommended (2) only for AES execution

# 11.4 Pressure transducer connector - M12 - 5 pin - only for /W option D


PIN	SIGNAL	TECHNICAL SPECIFICATION	Voltage	Current
1	VF +24V	Power supply +24Vpc	Connect	Connect
2	TR	Signal transducer maximum range $\pm 10$ Vpc / $\pm 20$ mA, software selectable Defaults are 0 $\div$ 10 Vpc for standard and 4 $\div$ 20 mA for /C option	Connect	Connect
3	AGND	Common GND for transducer power and signals	Connect	/
4	NC	Not Connect	/	/
5	NC	Not Connect	/	/

### 11.5 Solenoid connection - only for DPZO-A

PIN	SIGNAL	TECHNICAL SPECIFICATION	Connector code 666
1	COIL	Power supply	253
2	COIL	Power supply	
3	GND	Ground	



### 12 CONNECTORS



# MODEL CODES OF MAIN CONNECTORS AND COMMUNICATION CONNECTORS - to be ordered separately

VALVE VERSION	A (1)	AEB, AES std and /Q	AEB, AES /Z and /W	AEB, AES /W	BC - CANopen	BP - PROFIBUS DP	EH - EtherCAT
CONNECTOR CODE	666	ZM-7P (A1)	ZM-12P (A2)	ZH-5PM/1.5 (D)	ZM-5PF ©1	ZM-5PM/BP©2	ZM-4PM/E ©3
		ZH-7P (A3)	ZH-12P (A4)				ZM-4PM/E C4
PROTECTION DEGREE	IP67	IP67					
DATA SHEET	K500 GS115, K500						

(1) Connector supplied with the valve

only for AES

### 14 PROGRAMMING TOOLS - see tech table GS500

Valve's functional parameters and configurations, can be easily set and optimized using Atos E-SW programming software connected via USB port to the digital driver. For fieldbus versions, the software permits valve's parameterization through USB port also if the driver is connected to the central machine unit via fieldbus.

The software is available in different versions according to the driver's options


IR (Infrared) E-SW-BASIC support: NP (USB) PS (Serial) **E-SW-FIELDBUS** support: BC (CANopen) BP (PROFIBUS DP) EH (EtherCAT) EW (POWERLINK) EI (EtherNet/IP)

E-SW-\*/PQ support: valves with SP, SF, SL alternated control (e.g. E-SW-BASIC/PQ)

#### WARNING: drivers USB port is not isolated!

The use of isolator adapter is highly recommended for PC protection (see table **GS500**)

### **USB** connection




#### 15 PLUGS LOCATION FOR PILOT/DRAIN CHANNELS


Depending on the position of internal plugs, different pilot/drain configurations can be obtained as shown below. To modify the pilot/drain configuration, proper plugs must only be interchanged. The plugs have to be sealed using loctite 270. Standard valves configuration provides internal pilot and external drain




Internal piloting: blinded plug SP-X300F ① in X; External piloting: blinded plug SP-X300F ② in Pp; Internal drain: blinded plug SP-X300F ③ in Y; External drain: blinded plug SP-X300F 4 in Dr.












Internal piloting: Without blinded plug SP-X300F ①; **External piloting**: Add blinded plug SP-X300F ①; Without blinded plug SP-X300F 2: Internal drain: External drain: Add blinded plug SP-X300F 2.





Internal piloting: Without blinded plug SP-X500F ①; External piloting: Add blinded plug SP-X500F ①; Without blinded plug SP-X300F 2: Internal drain External drain: Add blinded plug SP-X300F ②.





Internal piloting: Without plug ①; External piloting: Add DIN-908 M16x1,5 in pos ①; Add plug SP-X325A in pos 2; Without blinded plug SP-X300F 3; Internal drain: External drain: Add blinded plug SP-X300F 3.

To reach the orefice ② remove plug ④ = G1/8"

# 16 INSTALLATION DIMENSIONS FOR DPZO-1 [mm]

ISO 4401: 2005

Mounting surface: 4401-05-05-0-05 (see table P005)

Fastening bolts:

4 socket head screws M6x40 class 12.9


Tightening torque = 15 Nm Seals: 5 OR 2050; 2 OR 108

Diameter of ports A, B, P, T:  $\emptyset = 11$  mm; Diameter of ports X, Y:  $\emptyset = 5$  mm;


125


Mass [kg]


	Α	AEB, AES	AES-EH
DPZO-*-15*	7,7	8,1	8,2
DPZO-*-17*	8,6	9	9,1
Option /G		+0,9	





125











Dotted line = double solenoid version

1 = Space to remove the 7 or 12 pin main connector. For main and communication connector see section [12], [13]

# 17 INSTALLATION DIMENSIONS FOR DPZO-2 [mm]

#### ISO 4401: 2005

Mounting surface: 4401-07-07-0-05 (see table P005)

Fastening bolts:

4 socket head screws M10x50 class 12.9

Tightening torque = 70 Nm

2 socket head screws M6x45 class 12.9 Tightening torque = 15 Nm


Seals: 4 OR 130; 3 OR 109/70 Diameter of ports A, B, P, T: Ø = 20 mm;


Diameter of ports X, Y:  $\emptyset = 7$  mm;

### Mass [kg]


	Α	AEB, AES	AES-EH
DPZO-*-25*	11,9	12,3	12,4
DPZO-*-27*	12,8	13,2	13,3
Option /G			

### DPZO-A-2







#### DPZO-AEB-NP-2








### DPZO-AES-EH-2



option /G



Dotted line = double solenoid version

# 18 INSTALLATION DIMENSIONS FOR DPZO-4 [mm]

#### ISO 4401: 2005

Mounting surface: 4401-08-08-0-05 (see table P005)

Fastening bolts:

6 socket head screws M12x60 class 12.9


Tightening torque = 125 Nm Seals: 4 OR 4112; 2 OR 3056


Diameter of ports A, B, P, T:  $\emptyset$  = 24 mm; Diameter of ports X, Y:  $\emptyset$  = 7 mm;

### Mass [kg]


	Α	AEB, AES	AES-EH
DPZO-*-45*	17,1	18	18,1
DPZO-*-47*	18	18,9	19
Option /G		+0,9	

### DPZO-A-4







# DPZO-AEB-NP-4








### DPZO-AES-EH-4



option /G



Dotted line = double solenoid version

① = Space to remove the 7 or 12 pin main connector. For main and communication connector see section ② , ③

# 19 INSTALLATION DIMENSIONS FOR DPZO-6 [mm]

#### ISO 4401: 2005

Mounting surface: 4401-10-09-0-05


Fastening bolts:


6 socket head screws M20x90 class 12.9 Tightening torque = 600 Nm Diameter of ports A, B, P, T: Ø = 34 mm; Diameter of ports X, Y: Ø = 7 mm;

Seals: 4 OR 144, 3 OR 3056


### Mass [kg]

	Α	AEB, AES	AES-EH
DPZO-*-65*	42,1	42,5	42,6
DPZO-*-67*	42,7	43,1	43,2
Option /G		+2,3	







### DPZO-AEB-NP-6




#### DPZO-AES-BC-6 DPZO-AES-BP-6



### DPZO-AES-EH-6



### option /G



Dotted line = double solenoid version

1 = Space to remove the 7 or 12 pin main connector. For main and communication connector see section 12, 13